GSA STUD ADHESIVE

Description
A specially formulated adhesive/nail or adhesive/screw application of plasterboard or wallboard to timber or metal frames.

Recommended Uses: Bonding plasterboard to timber or metal building framing. Suitable pine softwood framing Suitable for hardwood framing

Preparation: Framing must be free of oil, grease or other foreign materials to ensure a good bond. Fix board within 30 minutes of applying the adhesive to the frame.

Application:

WALLS
1. Apply adhesive to the stud with a broad knife, using enough material to form 'walnuts' of adhesive 25mm in diameter & 15mm high.
2. Apply 'walnuts' at 230mm maximum & 200mm minimum centres from the nailing point at sheet edges
3. Apply plasterboard horizontally, nailing along the one recessed edge at each stud.
4. Press the sheet firmly against the studs, then nail along the second recessed edge at each stud.
5. Hold the sheet against the studs for 24 hours by nails driven through a temporary plasterboard block on the centre line of the sheet on every second stud.
6. Nail ends of sheet at butt joints at 150mm centres & internal or external corners at approximately 300mm centres.
7. Screw around all openings at 300mm centres. 'Walnuts' of adhesive must NEVER coincide with fixing points.

CEILING
1. Apply 'walnuts' at 230mm maximum & 200mm minimum centres from each board edge.
2. DO NOT place 'walnuts' where centre screws will be driven. 'Walnuts' should be located at least 200mm away from fixing points.
3. Apply plasterboard with paperbound edges at right angles to the joints.
4. Screw recessed edge to each joist. Then along the centre of every board at each joist, drive screws 50mm to 75mm apart.
5. Screw second recessed edge.
6. Screw ends of the boards at butt joints and around service openings at 150mm centres.
7. For a cornice finish, screw the ends of the boards at 300mm centres.
8. Under slow drying conditions, hold 1350mm wide boards against the framing members with temporary blocks for at least 48 hours.
9. 'Walnuts' of adhesive must NEVER coincide with nailing points.

Clean-Up: Clean up with water.

Storage: Replace lid tightly when not in use. Do not freeze. Store in a cool, dry place.

First Aid: Please refer to the Safety Data Sheet which is available at www.cwbrands.com.au/



GSA STUD ADHESIVE

Disclaimer

CW Brands Pty Ltd believes that the information in this technical data sheet is an accurate description of the typical uses of the product. The data and statements are based on our research and development work and is to the best of our knowledge true and accurate. The user must ensure of the product(s) in their application prior to use in particular to determine its performance, efficiency and safety. The use of this product is beyond the manufacturer's control, and liability is restricted to the replacement of material proven faulty. The manufacturer is not responsible for any loss or damage arising from incorrect usage. Products conform solely to the information contained in this and other related CW Brands Pty Ltd publications.

CW Brands Pty Ltd reserves the right to make changes to specifications and information related to the products at any time. Users are asked to check that the literature in their possession is the latest issue. Statements contained herein should not be considered as a warranty of any kind, expressed or implied in describing the performance or suitability of the product for a particular application. No liability is accepted for infringement of any patents or any other intellectual property right.